

Rough Opening Template

Do Not Throw This Away!

13 7/8"

Radius
6 15/16"

29 1/4"

KB112-01RE Rough Opening Template

Step 1

Secure template over desired surface for mounting the KB112-01RE Recessed Laybed.

Step 2

Drill hole to start saw on inside of traced rough opening.
Use saw to cut out rough opening.

Step 3

See installation instructions for more information on mounting.