

KB103 CLASSIC HIGH CHAIR REPLACEMENT WHEEL INSTRUCTIONS

P/N 741-KIT

Tools Required:

Hammer
Pliers

Materials Included:

Two Axle Pins
Two Wheels

1. Lay the chair face down on the floor or a table.
2. Locate the wheels on the bottom of the chair; each wheel is held in place with an axle pin.
3. Grip the axle pin with a pair of pliers and push it towards the outside of the chair. (This could require some force.)
4. When enough of the axle pin is exposed on the outside of the chair leg that you can grip it with the pliers, do so and pull the axle pin completely out of the chair.
5. Repeat steps 3 and 4 for the opposite wheel. Discard the old axle pins and wheels.
6. Take one of the new axle pins and (using a hammer) tap it into the hole where the old axle pin was removed. Stop hammering once the axle pin is visible in the recessed area for the wheel.
7. Take one of the new wheels and line up the center hole with the axle pin. Hold the wheel in place while you hammer the axle pin through it.
8. Once the axle pin is through the wheel, align it with the recessed hole on the inside edge of the wheel recess and hammer the axle pin into it until it is flush with the outside of the chair.
8. Repeat steps 6, 7 and 8 for the other wheel.
9. Check that each wheel spins freely. Clean the chair before using.

