

KB100, KB101, KB110, KB111 REPLACEMENT LINER LID INSTRUCTIONS

P/N 827-KIT, 828-KIT, 829-KIT, 830-KIT

Tools Required:

Phillips Head Screwdriver

1. Remove the changing station from the wall.
2. Locate the horizontal slot on the back of the unit next to the top of the shock.
3. Take the replacement liner dispenser lid and insert into the slot. The plastic lip should remain on the outside of the unit.
4. Open the unit to ensure the lid is positioned correctly.
5. Remount the unit to the wall.

